Setting Up Clearstreams



Step 1 Open frame and pull one side of the bag through the opening.

Step 2 Fold bag over the top of the frame, catching the edge and pulling tight.





